



ARCHITECTURAL
MAILBOXES®

4X4 PINE WOOD POST INSERT KIT

Poste de madera de pino

Poteau en bois de pin

INSTALLATION INSTRUCTIONS *Instrucciones de Instalación*

Tools Required (not included):

Herramientas necesarias (no incluido):

Hammer
Martillo



Level
Nivel



Safety Glasses
Gafas de seguridad



- 1** Position and pound anchor into the wood post.

Posición y martillo ancla en el poste de madera.

- 2** Make sure one side of the post is parallel to the street. Using a hammer, gently drive the post to ground level straightening the post as you hammer.

Asegurar un lado de poste es paralelo a la calle. Usar una martillo, suavemente martilla el poste a suelo nivel enderezando el poste como martilla.

